
INSTRUCTIONS FOR MODELS

SA-2303 TOWEL RACK SA-2304 TOWEL RING SA-2305 PAPER HOLDER SA-2306 ROBE HOOK SA-2307 TOWEL BAR



NEED HELP?

For additional assistance or service please contact:

SPEAKMAN® Company 400 Anchor Mill Road New Castle, DE 19720









92-SA-2300-03

TOOLS AND SUPPLIES







IMPORTANT



- Do not over-tighten any connections or damage
- Be sure to read instructions thoroughly before beginning installation.

SAFETY TIPS

Cover your drain to prevent loss of parts.


MAINTENANCE

•


Your new Speakman Product is designed for years of trouble-free performance. Keep it looking new by cleaning it periodically with a soft cloth. The use of harsh chemicals and abrasives on any of the Speakman custom finish products may damage the finish and void the product warranty. Please be sure to only use approved cleaners. Please contact Speakman for any clarification of acceptable cleaners.

WARRANTY


Additional warranty information can be found at: www.speakman.com




At the selected height, mark center point of mounting locations onto wall referencing the rough in diagram.




Align Mounting Plate over center point marked in previous step. Mounting Plate should be vertical as shown below. Mark Mounting Screw locations onto the wall surface. Remove items after marking mounting locations.




If mounting directly to wood stud, Plastic Anchors are not required. If mounting to tile, acquire proper mounting hardware capable of supporting the accessory in use. If mounting to drywall, drill guide holes at marked locations using a Drill equipped with a Ø 3/16" bit.





Insert Plastic Anchors into drilled holes and screw in the anchor using a Phillips Head screwdriver, or a Drill equipped with a Phillips Driver Bit until the head is flush with the wall surface.




Secure Mounting Plate with the Mounting Screws provided. Verify that the Mounting Plate is aligned vertically.










ROUGH-IN DIAGRAMS






SPEAKMAN®







DIMENSIONS SUBJECT TO CHANGE WITHOUT NOTICE.