
LOCATION

GUARDIAN DUAL CHECK HYDRANT PARTS LIST



Installer is responsible for providing a 100% watertight positive seal at the hydrant to box interface and hydrant to wall interface. Seal all interior joints, seams, gasket seams/closures including around the hydrant box flange with an appropriate sealant recommended by a sealant manufacturer. NOTE: Jay R. Smith does not warrant the performance or life expectancy of the sealant material.

HYDRANT PARTS LIST										
NO.	DESCRIPTION	NO.	DESCRIPTION	NO.	DESCRIPTION	NO.	DESCRIPTION			
1b 1c 2 3 4 5	Casing Assembly Head Casing Valve Housing Wall Plate Assembly Key Wall Plate Securing Screw (5) Wall Plate Gasket Stationary Operator Piece	7 8 9 10 11 12 12a 12b 12c	**Spring (2)	12e 12f 13 13a 13b 13c 13d	**Small O-Ring **Flow Diverter **Large O-Ring Actuator Cartridge Assembly **Retaining Ring **Valve Body **Actuator O-Ring (2) **Nylon Thrust Spacer **Valve Actuator	13f 13g 13h 13j 13k 13m 14 15 20	3			

					WEIGHT POUNDS	VOLUME CUBIC FEET	FIGURE NUMBER
Α	7-20-16	7-20-16 Added Note		BW			5519BS
REV.	DATE	DESCRIPTION	BY	CKD. BY			00.020